

4 Or 6 Programs (Events)

1. Tap the **MODE** button until you can see a snowflake on the display.
2. Press & Hold the **ALL DAY** button and **HOLIDAY** button and while holding these two, tap on the **>>** button. You will see either ON or OFF flashing on the display. Release the buttons.
3. Tap the **>>** button until you see CODE on the display.
4. Press the **>>** button once more and you will see an error code appear and then disappear. The error code will be replaced by number 4 or 6. This is the number of programs (events) that are set.
5. Use the **+** button to change between 4 & 6.
6. Press the **HOME** button to exit the menu.
7. Tap **MODE** until you can see AUTO or MAN.