

## Using Only 1 Program With Your ES RTP8

1. Hold the ►► button until the display shows RF SETUP.
2. Use the **DIAL** to select PROGRAM EVENTS
3. Press the ►► button
4. Use the **DIAL** to select 4
5. Press the ►► button
6. Press the ►► button again
7. Use the **DIAL** to select HEATING SCHEDULE
8. Press the ►► button
9. Look at the bottom of the display to check which program mode you are in.
10. Use the **DIAL** select the program mode from the following:
  - **5/2day** – this mode allows 1 set of programs for weekdays and a different set of programs for weekends.
  - **24Hour** – this mode will use the same programs every day.
  - **7day** – this mode allows different programs every day.

### You must select 24HOUR

11. Press the ►► button, MON—SUN will be flashing at the top of the screen.
12. Press the ►► button again
13. Use the **DIAL** to set a start time. Press the ►► button.
14. Use the **DIAL** to set an end time. Press the ►► button.
15. Use the **DIAL** to set a comfortable room temperature, e.g. 20c. Press the ►► button.
16. The previous end time will be flashing, you can ignore this. Press the ►► button.
17. Ignore the next end time. Press the ►► button.
18. Use the **DIAL** to set a low temperature, e.g. 14c. Press the ►► button.
19. Ignore the next start time. Press the ►► button.
20. Ignore the next end time. Press the ►► button.
21. Use the **DIAL** to set the same low temperature as step 18 above. Press the ►► button.
22. Ignore the next start time. Press the ►► button
23. Ignore the next end time. Press the ►► button.

24. Use the **DIAL** to set the same low temperature as step 18 above. Press the ►► button.

25. Press the **HOME** button to exit the menu.

26. Tap **MODE** until you can see AUTO on the display.

*The times & temperatures above are examples only.*