

Connecting Your Series 6 Thermostat To Centro

1. Download the **ESi Centro** app (NOT ESi Centro Smart).
 2. Create an account using your email address and a memorable password.
 3. Switch your home router off for 1 minute & switch it back on again to ensure the latest firmware is correctly installed.
 4. *On your thermostat*, tap the **HOME** button to wake the screen.
 5. Tap the **MENU** button and you will see **WIFI SETUP**.
 6. Tap on the **HOME** button and you will **WIFI SETUP PAIRING**.
 7. *On your mobile device*, log in to your new Centro account and you should arrive at a screen showing **Heating Control** and **Hot Water**.
 8. Tap on **Heating Control**. You will arrive at a screen showing **Add New Device** at the bottom of the screen.
 9. Tap on **Add New Device** and select the top option, **RTP6**.
 10. On the next 3 screens tap **YES**.
 11. You will arrive at a screen titled **Choose Network**. Your home network should be in the top box. If it is not there, ensure your router is broadcasting at 2.4ghz.
 12. Tap the lower box and enter your WiFi router password. This is case sensitive.
 13. Tap on **Remember Password**.
 14. Make sure **Normal Config** is selected.
 15. Tap on **Next**. Your Centro app will search for your room thermostat and when pairing is successful, it will show **Configuration completed successfully**.
 16. Tap on **Confirm** and you will see your thermostat listed on the **Heating Control** Screen.
 17. If your thermostat doesn't bond with Centro, try the above steps again.
- If your thermostat doesn't bond with Centro the second time, follow the steps below
18. On the screen titled **Choose Network**, select **AP Config**.
 19. Tap on **Next**.
 20. *On your thermostat*, hold a finger on the HOME button until the screen shows **AP**.
 21. *On your Centro app*, tap on **YES**.
 22. The next screen shows a mobile phone's WiFi settings, tap on **YES**.

23. A window will pop up informing you to return to the app when you have selected RTP6 in your WiFi settings. Tap on **GO**.
24. Your phone settings should open, make sure the Location setting is set to **While Using**.
25. Navigate to your phone's WiFi settings.
26. From the listed networks, choose **thermostat-RTP6**.
27. When this is selected, make your way back to the ESi Centro app and tap on **YES**.
28. Centro will now bond directly with your thermostat instead of going through your router. This will only happen during the setup process. Once setup is complete, your phone will return to your home WiFi.
29. When setup is complete, your Centro app will show **Configuration completed successfully**.
30. Tap on **Confirm**.

During setup, your phone may ask you for permission to allow ESi Centro access to parts of your phone, please allow these to be able to advance.