

Programmer – Setting Hot Water Programs

1. Move the slider bar to the **HW** position.
2. Use the **+/-** buttons to choose between
 - **5/2 Day** – One set of programs for weekdays and a different set of programs for weekends.
 - **24 Hour** – Every day will run the same programs.
 - **7 Day** – Every day can run different programs and all days **MUST** be set.
3. Use the **>>** button to move onto your first program.
4. Use **+/-** to set the start time for your first program.
5. Press **>>** to move onto the end time for your first program.
6. Use **+/-** to set the end time for your first program.
7. Press **>>** to move to the start time for your second program.
8. Use **+/-** to set the end time for your second program.
9. Press **>>** to move onto the end time for your second program.
10. Move the slider bar to **RUN**.