

## Series 4 – Set The Time & Date

1. Move the slider bar to the TIME/DATE position - as far to the left as it will go.
2. The hour digits will be flashing. Use +/- to set the correct hour. Press the >> button and you should see the minute digits flashing
3. Use +/- to set the correct minutes. Press the >> button and you should see the first date digits flashing.
4. Use +/- to set the correct day of the month. Press the >> button and you should see the month digits flashing.
5. Use +/- to set the correct month. Press the >> button and you should see the year digits flashing.
6. Use +/- to set the correct year. Press the >> button and you should see the time format flashing.
7. Use +/- to select either 12 hour clock or 24 hour clock.
8. Move the slider bar to either OFF, MAN or AUTO