

## <u>Series 6 – Lock</u>

The Series 6 room thermostat has 2 types of lock – Partial or Full.

## Partial Lock

- 1. Press the **HOME** button this is the circular button under the display.
- 2. Press the **MENU** button this is the button with 3 horizontal lines under the display.
- 3. Tap <sup>V</sup> until you see **SCREEN LOCK**.
- 4. Press HOME you should see SCREEN LOCK PARTIAL
- 5. Press **HOME** you should see **PARTIAL LOCK HOME**
- 6. Press HOME you should see SAVING

The screen will revert to your HOME screen, pressing any button will show **SCREEN LOCK**. You will not be able to adjust the temperature setting.

## **Remove Partial Lock**

- 1. Press **HOME**, **SCREEN LOCK** should show on the screen.
- 2. <u>HOLD</u> the **MENU** button, keep it pressed **until SCREEN LOCK** disappears.
- 3. Press **HOME** to choose your heating preference between **HOME**, **MANUAL**, **AWAY** & **SLEEP**.

## Full Lock

Full Lock can only be implemented by inserting the correct PIN (Password). The default PIN is 0000 so it is advisable to change the PIN before setting Full Screen Lock.

- 1. Press the **HOME** button to wake the display.
- 2. Tap on the **MENU** button, the display will show WIFI SETUP or SET TIME
- 3. Tap the  $^{\mathbf{V}}$  button 3 times and you should see SCREEN LOCK
- 4. Tap the **HOME** button, the display will show SCREEN LOCK PARTIAL
- 5. Tap the <sup>A</sup> button to show SCREEN LOCK FULL
- 6. Tap the **HOME** button and the word 'HOME' will flash
- 7. Tap the **HOME** button
- Enter your PIN. Use the ^ & V buttons to select a number and use the HOME button to move to the next digit.
- 9. Press the **HOME** button to confirm.
- 10. Set the MINIMUM TEMPERATURE by using the **^** & **V** buttons.
- 11. Press the **HOME** button
- 12. Set the MAX TEMPERATURE by using the **^** & **v** buttons.
- 13. Press the **HOME** button and you should see SAVING.

The display will show your HOME screen. The temperature can now only be adjusted by the end user between the minimum & maximum temperatures you entered above. To cancel FULL SCREEN LOCK, press the **HOME** button and enter your PIN.