

## Programmer – Setting Heating Times

1. Move the slider bar to the **HEATING** position.
2. Use the +/- buttons to choose from:
  - **5/2 Day** – One set of programs for weekdays and a different set of programs for weekends.
  - **24 Hour** – Every day will run the same programs.
  - **7 Day** – Every day can run different programs and all days **MUST** be set.
3. Use the >> button to move onto your first program.
4. Use +/- to set the start time for your first program.
5. Press >> to move onto the end time for your first program.
6. Use +/- to set the end time for your first program.
7. Press >> to move to the start time for your second program.
8. Use +/- to set the end time for your second program.
9. Press >> to move onto the end time for your second program.
10. If you have a 3 channel programmer, you will need to continue setting programs for heating zone 2.
11. Move the slider bar to **RUN**