

Programmer – Choose 12 or 24 Time Format

1. Move the slider to the **RUN** position
2. Hold the **HOME** button, - button and **DAY** button until you see **2** flashing
3. Release the buttons
4. Press **>>** 3 times and you should see **12H** flashing on the screen
5. Use **+** to select between 12 or 24 hour time format
6. Press the **HOME** button to exit the menu