

FSWC1

Wiring Centre

User and Installation Instructions

The ESWC1 Wiring Centre is designed to be a safe and convenient method of system wiring. The ESWC1 provides a safe means of connection whilst reducing installer time by simplifying the wiring and circuit testing, with a dedicated terminal block for each system component. The ESWC1 is suited to all popular heating systems and manufactured in a robust fire retardant ABS.

Installation

Always isolate the AC mains before installing the wiring centre. Wire the system components to the correct terminals.



Wiring Centre	
Protection Rating	IP20
Maximum Ambient Temperature	55°C
Voltage Rating	230V 50/60Hz
Current Rating	10A
Fuse Rating	2A 230V 50Hz
Complies With:	EC Directive 2006/95/EC, EMC (89/336 & 92/32 EEC) BS EN 60730-1:2000 BS EN 60730-2-9:2002. LVD (73/23/EEC) (93/68/EEC) BS EN 60730-1:2000 BS EN 60730-2-9:2000)

WARNING: Interference with sealed parts renders the guarantee void. Always isolate the AC mains supply before removing or fitting the product. This accessory must be fitted by a competent person, and installation must comply with the guidance provided in the current editions of BS7671 (IEE wiring regulations) and part 'P' of the building regulations.

In the interests of continuous product improvement we reserve the right to alter designs, specifications and materials without prior notice and cannot accept liability for errors.